

## INSTALLING ACRYLIC REPLACEMENT HANDLES

Refer to the [Parts Breakdown Book](#) for replacement part numbers or [contact customer support](#) for help in finding a part

### You may need several of these tools:

Allen wrench (5/16 or 7/32)  
Channel locks  
Crescent wrench  
» Flathead screwdriver  
» Phillips head screwdriver  
Pipe joint compound  
Soft cloth  
Teflon tape  
No tools necessary

### Part key:

No.	Description
1	Index Button
2	Handle screw
3	Handle

1. Using a flathead screwdriver or knife, lift off index button, remove handle screw using a phillips head screwdriver, remove handle.
2. Slip new handle over stem and bonnet assembly.
3. Replace handle screw and index button.

