

Refer to the [Parts Breakdown Book](#) for replacement part numbers or [contact customer support](#) for help in finding a part

### You may need several of these tools:

- Allen wrench (5/16 or 7/32)
- » Channel locks
- Crescent wrench
- Flathead screwdriver
- Phillips head screwdriver
- Pipe joint compound
- » Soft cloth
- » Teflon tape
- No tools necessary

### Part key:

No.	Description
1	Showerhead
2	Flange
3	Shower arm

1. Unscrew old showerhead where it connects at the shower arm. There is no need to remove flange.
2. Wrap shower arm threads with teflon tape (optional).
3. Screw new showerhead onto shower arm. Tighten if necessary using channel locks. Wrap end of showerhead with soft cloth to protect finish.
4. Turn on water, check for leaks.

